

Quick Start Guide

TV, AUD, DVD, VCR or STB

Press TV, AUD, DVD or STB once to select a home entertainment device to control.

SETUP

Use SETUP for all programming sequences

SKIP BACK

Press SKIP BACK to instantly replay the last 7 seconds of the program you are watching.

REWIND

REWIND through parts of a recording or paused TV.

PLAY

Press to watch a recording.

PAUSE

Pause what you are currently watching.

MENU

Displays applications including the configuration menu.

GUIDE

Press GUIDE to open the Interactive Program Guide.

DAY +/-

Use DAY+ (or DAY-) to move a day forward (or back) on your program guide.

ARROW KEYS/OK

Navigate on screen choices.

RED, GREEN, YELLOW, BLUE

Access additional features on your set-top box.

VOL +/-

Raise or lower the volume.

MUTE

Turn the sound off or on.

ASPECT/*

Press TV, then ASPECT to temporarily change the aspect

INPUT/*

Press TV, then INPUT to select other video source.



POWER

Press POWER once to turn on or off a home theater device.

LIVE

Press LIVE to return to watching LIVE TV.

LIST

Press LIST once to display a list of recorded, future and series rules on your DVR.

SKIP FORWARD

Press SKIP FORWARD to jump ahead 30 seconds at a time.

FAST FORWARD

Fast forward through parts of a recording or paused TV.

RECORD

Press to record a show.

INFO

Display the current channel and program information. Press again for more detail.

EXIT

Exit the current screen.

PAGE +/-

Page up or page down in menu screens and the Interactive Program Guide.

CHANNEL +/-

Changes to the next higher or lower channel.

FAV

View your favorite channels.

LAST

Recall the last channel you were watching.

NUMBER KEYS (0-9)

Directly select a channel, ratio on your TV, forward in 30 second intervals.

*ON DEMAND

Not available at this time.

www.wcta.net



800-945-2163 | 218-837-5151


West Central
Telephone Association
We Connect You

What's on TV?

There's more than one way to see what's showing on TV.

INFO BUTTON

Press Info once for a brief description of the program you are viewing. Press Info again for more details.

OK BUTTON

Press OK to show the 'Now Playing' bar and you'll see what's currently showing.

GUIDE BUTTON

This is the most comprehensive view of what's on. Go ahead and page through... you're bound to find something to watch.

FAVORITES

You can create Favorites Lists. There are currently 6 pre-defined favorite named lists including All Channels, Subscribed Channels, Entertainment Channels, Religious Channels, Regional Channels and HD Channels.

To create your own Favorites List:

Press MENU, arrow down to SETTINGS then arrow over to EDIT FAVORITES. Press OK.

Next, press OK over each channel you wish to add to your Favorite List. When finished selecting channels, press the BLUE button to Save your List. You will be prompted to name the List.

Using Favorite Lists:

Press the GUIDE button, then the BLUE button to cycle through the Favorites Lists.

PARENTAL CONTROLS

To control the types of programming that can be viewed, you may want to set limits using PARENTAL CONTROLS.

Press GUIDE, then SETTINGS and PARENTAL. From there you can Change Pin, Edit Locked, Set Ratings, Set Time Restrictions, and Cancel Override.

REMINDERS

To set REMINDERS to watch specific programming, choose GUIDE, then highlight the program you want to set a reminder for and press OK.

You'll have the choice to Record One-Time, Series Record or Set Reminder. Choose Reminder, then decide if you want to set a One-Time Reminder, New Airings or All Airings, and whether you want to Auto-Tune to the program or not.

Check out these APPS!

WHAT'S HOT

The WHAT'S HOT application allows you to view local area real time information about what others with West Central TV are watching.

Choose MENU then arrow over to What's Hot and press OK. On the right side of your screen you'll see the list of the most popular TV, Series and Recordings by scrolling with the arrow keys.

If you press the YELLOW button on your remote while highlighting a program, you'll see when all instances of that program are available to watch.

WEATHER APP

Press the RED (C) Button. A window with local weather will pop up on your TV. Using your arrow keys, you can scroll to the left or right to choose your city.

Press the GREEN button to see the forecast; press the YELLOW button to see a radar map.

*Pressing the YELLOW (A) Button will take you to Weather, Games & What's Hot APPS.



West Central

Telephone Association

We Connect You.™

www.wcta.net



800-945-2163 | 218-837-5151